

ROOFER'S KIT (Model #VP801-2)

A Fall Protection Kit for Roof and Work-At-Height Workers

General

The roof anchors supplied in this kit are intended for single use only. The anchor is designed to mount on the peak of the roof. The anchor has been manufactured with a 30 - 40 degree angle. Before mounting on roof, adjust the angle to match the incline of the roof. When your job is completed, cut off the "D" - ring portion of the anchor and shingle over (The entire anchor may also be removed and discarded after use).

Mounting

The Model# RASU single use roof anchor has four inside holes and four outside holes on each side. **All 16 mounting holes must be used! Use 16d (penny) nails only!** Nails in all inside holes must be attached to a rafter, joist or truss. Nails in all outside holes must be attached to plywood sheathing. When attaching to a steel roof use #12 x ¾" min. length sheet metal screws threaded all the way to the head. **DO NOT USE** on steel roofs less than 20 GA. It is the user's responsibility to insure that Installed roof anchor is capable of supporting at least 5000 lbs.

Compliance: Meets applicable OSHA Regulations, ANSI Z359.1-1992 (R1999), ANSI A10.32-2004

Capacity: 310 lbs. (one worker including tools)

Use (Model # VP801-2 complete roofer's kit)

- 1) Inspect all equipment; Equipment showing signs damage or wear must not be used.
- 2) Mount roof anchor to peak of roof (see above).
- 3) Attach 5/8" rope lifeline to roof anchor using locking snap hook spliced to one end.
- 4) Attach rope grab to lifeline by threading on from free end
- 5) Attach locking snap hook at end of energy absorbing lanyard to the "D"-ring on the back of the harness.
- 6) Slide rope grab along lifeline to work position.

Read all instructions, warnings and labels before use.

- **Do not** use on exposed rafter, joists or trusses.
- **Do not** install within 4 feet of edge of roof.
- **Do not** nail or screw into decayed or substandard lumber.
- **Do not** attach more than one worker per anchor.
- **Do not** allow lifeline to become slack.
- **Do not** work above rope grab attachment point.
- **Do not** use lifeline horizontally.
- **Do not** use any equipment showing signs of damage or wear.
- System **must be** rigged so that an attached worker cannot swing fall (pendulum effect) and hit the ground or other obstruction.



RASU
Anchor



VF404WL3
Rope Grab



VP301-2
Lifeline



VP101-2
Harness

All equipment is stored in a sealable bucket, which keeps your Roofer's Kit protected while stored.



www.AllHandsFire.com

ALL HANDS FIRE EQUIPMENT, LLC

506 Atkins Avenue, Neptune, New Jersey 07753

Phone (732) 502-8060 • Fax (732) 502-8064 • sales@AllHandsFire.com